



DUX DYNAMIC CONNECTING PLATE

INSTRUCTIONS

DUX, DUXIANA and DUX Pascal-systems are registered trademark owed by Dux Design AB 2012.

Printed 2021.02.01

dux.com


TOOLS NEEDED



ASSEMBLING


I. LIFT BED UP






II. REMOVE FRONT AND BACK 'WOODEN BLACK SKIRT'

Repeat the same process on both beds.




III. JOIN BEDS TOGETHER



IV. ASSEMBLE THE NEW 'WOODEN CONNECTING PLATE'

Repeat the same process in the front.



CONSUMER CAUTION

Do not sit on the head- or foot-end while adjusting the bed.



TROUBLE SHOOTING

PROBLEM

Lift motors do not work at all.

POSSIBLE CAUSE AND CORRECTION

Power at wall outlet may be out; reset circuit breaker.

Power cord may be unplugged; plug in cord.

Hand control batteries are low; replace batteries.

PROBLEM

Head or foot section will not go all way down.

POSSIBLE CAUSE AND CORRECTION

Head or foot section may have an obstruction.

Move the bed to the up position, then remove the obstruction.

If the problem persists, contact Customer Service.

PROBLEM

Head or foot end will not go up or starts and stops intermittently.

POSSIBLE CAUSE AND CORRECTION

Contact the DUXIANA store or a DUX reseller.

All replacements and service should be performed by a DUX authorized service dealer.